

How to setup ReadyBoost® with *Patriot Memory* USB Flash Drives

1. Turn the computer on and insert Patriot Memory USB Pen Drive in an available USB port on the computer system.




2. Once the drive is attached to the USB port, please wait for 2~3 seconds for the drive to start the initialization process with windows Vista.



3. After the initialization is complete, the “AutoPlay” window will appear on your computer screen.
4. Simply click on “Speed up my system” for the setup to initiate.



5. Once setup initiates, the “Properties” window will appear on your computer screen.
6. Under the “ReadyBoost®” tab simply choose the amount of memory you want to dedicate to be used by ReadyBoost® by moving the Lever to the left or right.
7. Once the desired capacity is selected, click on “Apply”, then click on “OK”



8. ReadyBoost® will now automatically start the ReadyBoost® process.

Note:

1. ReadyBoost® initialization process will take 3~5 minutes depending on the amount of capacity set to be used by ReadyBoost®.
2. After setup is complete, the set up process will be saved on the pen drive automatically and will initialize every time the USB Pen Drive is attached to the computer that the setup process was originally initialized on.
3. ReadyBoost® will only work with Windows Vista Home Basic, Home Premium, Business, Ultimate, Enterprise, and Server versions only.
4. Maximum Capacity used by ReadyBoost® is 4GB.